

ANKLE SOFT RESTRAINT STRAPS

INSTALLATION INSTRUCTIONS

1. Lay the chair down on its back giving you better access to the frame area.
2. Make sure the strap is closed with both hook 'n loop latches meshed together.
3. Take the long tie strap and insert it between the flange and the frame.
4. Wrap it around the back of the chair frame and put it through both chrome rings.
5. Loop the tie strap back between the rings and push it through the bottom ring. Pull the strap tight but leave a small space between the frame and chrome rings.
6. Then secure the tie strap by tying a half hitch knot in the tie strap. This is done by looping the tie strap behind the chrome rings and bringing it back around front and putting it through the loop that's been created. Pull the strap tight.
7. Tie a 2nd half hitch in the same manner. Pull the strap tight.

