

ELBOW SOFT RESTRAINT STRAPS

INSTALLATION INSTRUCTIONS

1. Make sure the strap is closed with both hook 'n loop latches meshed together.
2. Take the long tie strap and insert it through the inside slot of the arm rest.
3. Wrap it around the bottom of the arm frame and put it through both chrome rings. The tie strap does not go up through the outside slot.
4. Make sure the 2 chrome rings are below the edge of the arm rest while you loop the tie strap back between the rings and push it through the bottom ring. Pull the strap tight.
5. Then secure the tie strap by tying a half hitch knot in the tie strap. This is done by looping the tie strap behind the chrome rings and bringing it back around front and putting it through the loop that's been created. Pull the strap tight.
6. Tie a 2nd half hitch in the same manner. Pull the strap tight.

